


**BEFORE PRINTING TURN OFF ANY SIZE ADJUST SETTING ON YOUR PRINTER,
VERIFY PRINTED HOLE SIZES BEFORE DRILLING**


DPM4 DRILL TEMPLATE

Cut and tape this template on your chassis to use a guide.
Re space the connectors and PCB as desired.



Handle the PCB with static electricity precautions - touch a grounded source to discharge static electricity before touching the PCB

WIRING DIAGRAM Top View



Mount XLR connector as desired. Recommended wire: 24 AWG stranded & twisted together. Connect pins 2 and 3 only from the XLR input connector to the PCB labeled "Input A" pins 2 & 3.

Take care AND inspect that the wires do NOT short. Check for stray wires that could short.

IMPORTANT NOTE - TERMINATE ALL NON LOOP THRU CONNECTORS BY SOLDERING A 120 OHM RESISTOR BETWEEN PINS 2 AND 3. TERMINATE ALL UNUSED LOOP THRU CONNECTORS.